



# INSTRUCTIONS FOR REMOVING AND REPLACING CHIPS




LOCATE THE REMOVABLE CHIP IN THE ECU.



REMOVE THE CHIP USING A REMOVAL TOOL. TRY RADIO SHACK IF YOU DON'T HAVE ONE.



INSERT THE BACK ROW FIRST TO INSURE THAT ALL PINS ARE IN THEIR SOCKETS.



INSERT THE FRONT ROW OF PINS AND PUSH CHIP FULLY INTO THE SOCKET. INSPECT THAT ALL PINS ARE IN THEIR SOCKETS.